

## M900 Parts List

parts no.	description	q'ty	parts no.	description	q'ty
1	Main Frame	1	43	Plastic Brake Bass	1
2	Rear Ground Tube	1	44	Bolt M8*P1.25*20L	1
3	Groung Tube Fixed Bolt	4	45	Sleeve 8mm*11mm*12L	1
4	Washer	4	46	Nut M8*P1.25	1
5	Nut	4	47	Screw M5*P0.8*6L	2
6	Front Ground Tube	1	48	Sleeve8mm*15L	1
7 R/L	Pedal	1	49	Screw M5*P0.8*15L	8
8	V Block	2	50	Screw M8*P1.25*8L	1
9	Bottle Cage	2	51	Left Inner Cover	1
10	Bottle cages fixed screw	4	52	Left Out Cover	1
11	Handle Bar	1	53	PU Moving Wheel	2
12	Handle Bar and Seats Lock Lever	2	54	Front Ground Tubes End Cap	2
	Spring Washer	2	55	Bearing 608ZZ	4
13	Bottom Plate For Saddle Slider	1	56	Nut 8*30L W/M6*P1.0	2
14	Stem	1	57	Nut M6*P1.0*12L	2
15	Seat Post	1	58	Rear Ground Tubes End Cap	2
16	Saddles Slider	1	59	BB Axles Bearing SKF 6004ZZ	2
17	Saddle	1	60	Sleeve 24OD*20.1ID*27L	1
18	Lock Lever For Stem And Seat	2	61	B.B Axle 25mm*20mm*128L	1
19	Set Screw M6*P1.0*8L	2	62L	Left Crank 175L	1
20	Plastic Seal cover	2	62R	Right Crank 175L	1
21	Axles Adjust ScrewM6*P1.0*95L	2	63	Flange Nut	2
22	POP Cover	2	64	Dusty Cover	2
23	Plastic Sleeve	4	65	Lock Nut M20*P1.0	1
24	Stem & Seat Post End Cap	2	66	Spring Washer	4
25	Bottom Plate for Handle Bar	1	67	Bolt M10*P1.5*15L	4
26	Safety Bolt	1	68	Pulley 265mm*5PK*21T	1
27	Adjust Knob	1	69	Right Out Cover	1
28	Moving Part 20 OD*34L	1	70	Right Inner Cover	1
29	Lock Nut 3/8" *16t*6T	1	71	Screw M5*P0.8*10L	2
30	Nut	2	72	Out Alloy Ring of Fly Wheel	1
31	Washer18mm*8.5mm*1.5t	2	73	Inner Cast Iron Fly Wheel	1
32	Spring 18mm*2mmD*65L* 9	1	74	Sleeve For BB Axle	1
33	Stud 12.7mm*160L	1	75	Bearing for Fly Wheel SKF 6203ZZ	2
34	Nylon Plug	1	76	Nut M17*P1.0*8t	2
35	Nut	1	77	Fly Wheels Axle	1
36	Brake set adjuster	1	78	Screw M5*P0.8*6L	5
37	Nut M8*P1.25	1	79	Nut M12*P1.25	2
38	Brake set Fix Bracket	1	80	Washer 27mm*13mm*3t	2
39	Washer	2	81	Nut3/8"*16t*6T	2
40	Screw M6*P1.0*15L	2	82	Rear Ground Stablize Adjuster	2
41	Magnetic Side Cover	2	83	Belt 5PK	1
42	Magnetic	6			

# M900 Diagrams

